



email tony@anthonyshive.com asap to order your roll of full color custom labels. All you will need is a high resolution square jpeg. Call or email with questions, 913-206-2188.

Lip Balm Kit – INSTRUCTIONS

1. Melt **Lip Balm Mixture** using a CLEAN warm water bath.
 - a. Use medium heat – ideal temperature is 125 degrees F.
 - b. Make certain that melted mixture can't spill into the water (if it does, let it cool and float to the top and repeat the process, this only works if you use CLEAN water to heat the pouch)
2. Apply labels to empty tubes.
3. Use syringe to transfer melted mixture into labeled tubes.
4. Allow to cool until solid.
5. Apply caps to tubes
6. Shrink Wrap
 - a. Slide filled and capped tubes into shrink leaves
 - b. Place into a large bowl or similar container
 - c. Heat with blow dryer on High. Move containers as needed to complete shrink wrap process

ENJOY!